

How To Care For Your Binoculars

Proper cleaning of the lenses is essential to maintaining the optical integrity of your binocular. Dirty lenses diminish the amount of light transmitted through the binocular and your overall viewing experience.

- 1. When wiping the lenses, use the lens cloth that comes with the binoculars, or a soft, lintless cloth.
- 2. To remove any remaining dirt or smudges, add one or two drops of isopropyl alcohol to the cloth.
- 3. Store your binocular in a moisture free area. Don't leave the binocular in a car on a hot/sunny day or near anything that generates heat as this may cause damage.

Warranty

saxon warrants that during the Warranty Period, your saxon product will, with normal use and service, be free of defects in materials and workmanship. For the binoculars, we provide 3-Years Limited Warranty. If warranty problems arise or repairs are necessary, contact the saxon customer service department if you live or the dealer where you purchased your binocular from.

The contact information can be found on last page of this user manual.

ScopePix Smartphone Adapter 2s



SKU# 645011

HikeSmart Harness



SKU# 170001

saxon

Splendour Trading Australia Company
Show us your gear & nature photos on

   #saxonoptics
#saxontelelescope #saxonbinoculars
#saxonmicroscope #fingerscrossedclearsky
Email: sales@saxon.com.au
Visit us at: www.saxon.com.au

saxon

TRAVELLER BINOCULARS



8x25 #140008
10x25 #140009
8-20x25 #143022
10-30x25 #143023

User Manual

saxon Traveller Binoculars will be your faithful companion through the tallest of mountains and buildings. Ergonomic lightweight and durable, these compact binoculars comes in a standard and zoom range to help you maximise your viewing needs. A must-have for anyone who is seeking to see the world and enjoy every moment of their adventure



CAUTION! Viewing the sun can cause permanent eye damage. Do not view the sun with this binocular or with the naked eye.

Adjusting The Interpupillary Distance (IPD)

The distance between the eyes, called "interpupillary distance," varies from person to person. To achieve perfect alignment of lens to eyes, follow these simple steps.

- 1. Hold your binocular in the normal viewing position.
 - 2. Grasp each barrel firmly. Move the barrels closer together or further apart until you see a single circular field.
- Always re-set your binocular to this position before using it.



Focusing

- 1. Close your right eye and sight an object with your left eye. Focus the binocular by rotating the center focus until the image is sharp and clear.
- 2. Open your right eye and close your left eye. Rotate the diopter adjustment ring until the object sighted is sharp and clear.
- 3. Both sides eyes are now in focus and you will need to use only the center focus wheel to focus on any object.

For Zoom Binocular Models

To increase or decrease power, move the zoom lever. To adjust focus you first zoom the binoculars to the highest power and then adjust the focusing system as above. Then, when zooming in and out your binoculars will be in focus.

Note For High Power Zooms

The higher powers show greatly magnified images for close-ups of objects when needed. However, keep in mind that the lower powers give you brighter and sharper images with the widest field of view. You may have to refocus when changing from low to high powers.

Tip: Eyeglasses worn for nearsightedness should be worn when using binoculars as you may not be able to obtain focus at infinity without them.